



Anyui Digital Taximeter









OPERATION MANUAL

OPERATION MANUAL FOR TAXIMETER

The following are functions of operation keys on the meter console.

[VACANT]

HIRED

STOP

F1

: This key is for child lock i.e. once the hire mode is on and the meter is working then by mistake if the stop key is pressed then the fare on the meter will not be changed. For releasing child lock the same key should be pressed again.

VACANT: When the driver Precess VACANT key the meter comes on FOR HIRE mode, this key is operated when the driver reaches destination & stops the waiting time, the printout is also received & the FORHIRE display gets ON.

HIRED

: This key is operated when the passenger boards the taxi & the taximeter is engaged. The FORHIRE light goes off.

STOP

: This key is operated when the trip comes to an end.

F2

: This key is pressed to eject the paper by 10 mm, so that the paper comes out of the printer console. It is also for AC/NON AC Tariff.


PRINTOUT: Press STOP key & then press VACANT key to take a print.

BUZZER

A buzzer sound is given at every paise drop to know that the meter is working.

DISPLAY

- The first small display on top left portion of window shows the time when the vehicle is in running more and while waiting it shows the waiting time.
- 2. The second small display on top right portion shows distance traveled in kms.
- The third big display shows whether the taxi is in FOR HIRE mode or shows the fare while in HIRED mode.





CUSTOMER INSTALLATION / CONFIRMATION REPORT

NO.:	_	DATE:
TAXI METER SR. NO).:	
MODEL	: SANSUI	04 / SANSUI 786 /
K FACTOR	:	
VEHICLE TYPE	:	
NAME OF OWNER	:	
MOBILE NO.	:	
VEHICLE REG. NO.	:	
PERMIT NO.	:	
I/WE HEREBY CONFIRM THE FOLLOWING		
DEMONSTRATION S	EEN	: YES / NO
TAXI METER WORKI	NG OK	: YES / NO
PRINTER WORKING	OK	: YES / NO
IT IS SOLEMNLY MY RESPONSIBILITY TO GET THE ROAD TEST DONE AND ONLY ON RTO SEALING AND CERTIFICATION OF THE TAXIMETER WITH PRINTER, I WILL PLY THE VEHICLE AS TAXI AS PER THE (G.O.)		
SIGNATURE / THUMB IMPRESSION OF DRIVER / VEHICLE OWNER:		
DEALER:		
PLACE.		



E-59, Marketyard, Near Krishi Panan Mandal, Gultekdi, Pune - 411037 Tel: 020-24206000

Fax:020-24206060

Email: info@sansuiscales.com

Mumbai Service: 9320606101, 9823044398 Sales: 9823197052

www.sansuiscales.com

Authorised Sales / Service in your area